



Installation:

1. Measure door width.
2. If needed, shorten. Make sure screw holes remain aligned.
3. Place vinyl insert into adjustable portion.
4. Insert vinyl feet.
5. Adjust height for tight seal.
6. Remove vinyl insert.
7. Floor surface should be clean.
8. For additional sealing, caulk both edges of threshold.
9. Screw into place. If using on concrete, pre-drill holes first and insert concrete anchors (not included) before screwing in place.
10. Press vinyl insert back into place.

Instalación:

1. Mida el ancho de la puerta.
2. Corte si es necesario. Asegurese que los agujeros para tornillos se mantengan alineados.
3. Coloque la inserción de vinilo en la parte ajustable.
4. Inserte los pies de vinilo.
5. Ajuste la altura para crear un sello seguro.
6. Remueva la inserción de vinilo.
7. La superficie del piso debe estar limpia.
8. Para sellado adicional, calafatee ambos bordes del umbral.
9. Atornille en su lugar. Si va a instalar en suelo de concreto, primero taladre agujeros e inserte anclas de plomo (no incluidas) antes de atornillar en su lugar.
10. Regrese y presione la inserción de vinilo en su lugar.

Helpful Hints:

To make the vinyl insert easier to install:

1. Soak in warm water for 10-15 minutes.
2. Apply a small amount of liquid soap to the edges.
3. Use a plastic (not aluminum) putty knife to press edges into groove.
4. Complete one side, then the other.

DAT39H

Silver

Thermwell Products Co., Inc.
Mahwah NJ 07430 Sparks NV 89431

